

# NuMI Extraction from MI

The MI accepts up to 6 proton batches ( $\sim 5 \times 10^{12} p/\text{batch}$ ) at 8 GeV from the Booster, accelerates  $8 \rightarrow 120$  GeV in  $\sim 1.5$  s. MI cycle types:

NuMI only: Every 1.9 seconds.

Batches 1-6  $\rightarrow$  NuMI in  $10 \mu\text{s}$


Mixed mode: Every 2.4-4 seconds.

Batch “1” (2 merged Booster batches “slip stacked” at  $8 \times 10^{12} p$ )  $\rightarrow \bar{p}$  source.

Batches 2-6  $\rightarrow$  NuMI in  $8 \mu\text{s}$ .

Tevatron store cycles: Once per day ( $\sim 2$  hrs).  $150 \text{ GeV } p \rightarrow$  Tevatron and  $\bar{p}$  from Pbar source accelerated to  $150 \text{ GeV}$  and injected into Tevatron.

Batch structure as measured in NuMI beamline



FERMILAB'S ACCELERATOR CHAIN

