
Geant4 based Water Cherenkov detector simulation

C. Walter / Duke University

The T2K 2KM MC



I am using this code as a base to build a new DUSEL WC simulation.

For T2K we designed a complex 2KM away from the neutrino source which included a 1 kton WC detector optimized to have the same performance as SK.


We used our experience from K2K and didn't try to copy the orientation and tube size of SK.


We built a flexible system in Geant4 and used it to simulate several geometries including the K2K tank so we could tune the simulation with real data.

2KM MC Characteristics and Features

- WC + Lar or FGD + MRD simulation
- Both 1kton and 2KM WC configurations with 8" and 20" PMTs
 - Tube placement handled programmatically.
- On the fly configuration via messengers
 - Geometry setup
 - Hadronic models
 - Generator type
 - Input/output file names
- Can read NUANCE format vector files (also have NEUT-> NUANCE converter)
- Root and PAW based outputs
- Raw and digitized hits based on SK-III style electronics
- Simplified pmt structure
- Water and reflective material parameters tuned to SK and K2K 1Kton data.
- Specialized G4 extensions to attach information to each photon
- Outputs geometry information for use by downstream programs
- External root based event display
- External conversions to SK format for reduction, display and and reconstruction


Variable PMT size






Comparison of pizero in GEANT4 8" and 20" 2km WC and SK viewed with SK event display.


Also simulate 1kton at K2K analyze data with modified SK tools and compare with real neutrino data






Multiple detectors and configurations

WIRED generalized event display that can read HEPREP files made by G4




Raw ROOT based event display with specialized features for pizero studies.



Same Pi0 event separated by parent γ in Root display (γ_1 = blue, γ_2 = red)

Water Cerenkov Detector: Event #1

Modified: WC and Root only




Example of visualization of two gammas decayed from a PiO

Water Cerenkov Detector: Event # 6


2 GeV muon run through the 2KM detector.

~ 10 sec/event




Reconstructed visualization from ROOT file information

Recorded Root information



Tree→JHF2kmRootEvent→JHF2kmRootTrigger



JHF2kmRootTrigger generally is the object to hold all of the information for each event (as there is only one RootTrigger for each RootEvent). Additionally there are accessor and mutator methods to access all of these pieces of information.


Again, more information on objects will be given in subsequent slides.

Tree→JHF2kmRootTrigger→JHF2kmRootEventHeader Event Number (Int_t fEvtNum) Date (Int_t fDate) Subevent Number (Int_t fSubEvtNum) Run Number (Int_t fRun)

The event header stores general information about the event. Some of these values (such as the subevent number) may just be set to zero.

Tree→JHF2kmRootTrigger→JHF2kmRootCerenkovDigiHit Tube ID (Int_t fTubeId) Tube ID (Int_t fTubeId) Charge (Int_t fQ) Time (Int_t fT)

Each object in this array contains the basic information for a PMT hit.



This array and the JHF2kmCerenkovHitTime array will only be filled if the system variable _SAVE_RAW_HITS is defined. This object will contain (in fTotalPe[1]) the total number of photoelectrons that hit the PMT. The value fTotalPe[0] can be used to look in the JHF2kmCerenkovHitTime array to get more details about the individual photoelectron hits.

Tree→JHF2kmRootTrigger→JHF2kmRootTrack



```
JHF2kmRootEvent (0)
JHF2kmRootEvent (1)

JHF2kmRootEvent (i<sup>th</sup> event)

JHF2kmRootTrigger[]

JHF2kmRootCerenkovDigiHit


JHF2kmRootCerenkovHits

JHF2kmRootTracks
```


Tree→JHF2kmRootTrigger→JHF2kmRootCerenkovHitTime

True time (fTruetime)


Parent ID (fPrimaryParentID)



As previously described, this is a large array of all raw photoelectron hits. The parent ID can also be used to see specifically where the photoelectron came from. In the visualization software, we use this value to display different colors for the two different decay gammas from a PiO.



In the case of the particle being a PiO, we save this information to aid with reconstructing the resulting cerenkov light from the two decay gammas.




The RootGeom is stored in a separate ROOT file. The structure specifies the size of the detector and the layout of the PMT's.

Modifications under way

- Converting to Water Cherenkov only.
- Root output only
- Addition of SK size and larger DUSEL size tank options and orientations.
- Removal of specific T2K/SK code.
- Setup for non-programmatic tube placement.

Crude Super-K III configuration


Missing exact tube placement and detailed PMT and FRP model.



WC Detector in debug mode, showing all PMT cells and black sheet.

2 GeV muon run through the detector.


~ 15 sec/event



WC Detector scaled to approximately Super Kamiokande size

Root based evt display for SK

Water Cerenkov Detector: Event # 2




DUSEL Size (53' x 54')

2 GeV muon run through the detector.


26720 20" tubes used for this configuration

~ 30 sec/event



Root Display

Water Cerenkov Detector: Event # 1



Next immediate steps

- Modify root display tools to handle bigger geometry and different event classes.
- Finish generalizing the code.
- Determine how to do tube placement
 - Important for SK validation
 - Exploring GDML which seems to be a the standard way of handling this in G4 and ROOT now.
- GDML is an XML based text description of materials and geometries.

Can be read in and out of G4 and ROOT and other solids programs.


Should allow for tube placement etc without recompilation.

```
XML Declaration
GDML Namespace
XML Schema Instance
                                <?xml version="1.0" encoding="UTF-8" ?>
Namespace
                                xmlns:gdml="http://cern.ch/2001/Schemas/GDML"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
GDML Schema Location
                                    xsi:noNamespaceSchemaLocation="schema/qdml.xsd" >
                                 <define>
                                <constant name="const1" value="100" />
Declaration of constants.
                                → <position name="pos1" unit="mm" x="0" y="0" z="0" />
positions, rotations, scalings,
                                <rotation name="rot1" unit="deg" x="const1" y="0" z="0" />
variables and matrices
                                  <scale name="scl1" x="-1" y="+1" z="+1"/>
                                 </define>
Definition of elements,
                                  materials>
materials, isotopes etc. Only
                                    <element Z="7" formula="N" name="Nitrogen" >
materials can be referenced
                                      <atom value="14.01" />
to volumes
                                   A</element>
                                    <element Z="8" formula="0" name="0xygen" >
                                      <atom value="16" />
                                    </element>
Simple material defined using
                                    <material formula=" " name="Air" >
fractions of elements defined
                                       <D value="0.00128" />
higher up.
                                      <fraction n="0.7" ref="Nitrogen" />
                                      <fraction n="0.3" ref="0xygen" />
                                    </material>
                                 </materials>
                                 <br/>
dids>
All solids to be used inside
                                  → <box aunit="radian" lunit="mm" name="world" x="10000" y="10000" z="10000" />
the geometry defined here
                                    <box aunit="radian" lunit="mm" name="det" x="2000" y="2000" z="2000" />
                                 </solids>
                                ₹<structure>
                                    <volume name="Detector" >
All volumes declared in the
                                      <materialref ref="Air" />
structure section.
                                       <solidref ref="det" />
                                    </volume>
World volume is declared
                                     <volume name="World" >
                                       <materialref ref="Air" />
                                       <solidref ref="world" />
                                       <physvol>
 Physical Volumes placed
                                        <volumeref ref="Detector" />
 inside a Logical Volume with
                                         <positionref ref="pos1" />
a specified position, rotation
                                        <rotationref ref="rot1" />
and scale
                                        <scaleref ref="scl1" />
                                      </physvol>
                                    </volume>
                                 </structure>
 The top volume of the
 geometry is specified
```

Goals

- GDML setups for:
 - SK size for validation
 - Strawman Design (from Kadel DUSEL Note # 73)
 - Larger mailbox design
- 20% and 40% coverage
- Check scattering / reflection etc
- Get the SK reduction chain working on output

Then we need to do real work...



Distribution

- I want this code to be available to everyone interested in large WC detectors and hope SK / SK-Gd and DUSEL and Memphis people will contribute to it.
- This will maximize the tuning and utility of the project.
 This is will be particularly useful for the postdocs we hire who are working on the existing experiments.
- This is similar to GLG4SIM for liquid scintillator.
- I will make this code available to all via SVN.
- We can imagine/engineer "experiment specific extensions" in the future but I don't think it is necessary now.
- Should be ready for all in a few weeks.

Conclusions

- Modified 2KM G4 Code for use as the DUSEL WC MC.
- Computation speeds look reasonable.
- The base code is almost ready for distribution.
- The next basic step is geometry layout and validation against existing data.